



Programmable Strip Cutter

Model : M-100

The **SS** Programmable Strip Cutter Model M-100 is a guillotine type programmable shear that can cut card or web stock into strips of desired width. This is a very rugged machine.

M-100 is run by an inbuilt microcomputer which can be easily programmed by a 16 key keypad and LCD display provided on the front panel.



SPECIFICATIONS

Maximum Card Width	120mm
Cut Width	2–12mm
Power	220 V, 50 Hz
	110 V, 60 Hz
Dimension	49cm X 36cm X 32cm (H)
Weight	40Kg

FEATURES

- The cutting speed is about 12000 cuts per hour.
- Cutting speed can be varied.
- The blades are easily replaceable and are made of hardened alloy steel.
- In normal operation, 1 million cuts can be made without the need for sharpening.
- The number of strip that are cut is programmable and can be varied as per requirement from 1 to 9999.
- The width of the strip is also programmable from 2mm to 12mm.
- The machine can cut laminate of width upto 12cm.
- Keyboard entry for strip width definition.
- Emergency STOP switch.
- One-year warranty against manufacturing defect.

ORDERING INFORMATION

Programmable Strip Cutter Model M-100. Please specify the operating voltage.

DSTM70ZZZ1011G